

GRILL TURISMO™ 4-BURNER GRIDDLE Assembly Manual

085-0106-8 (G70220)

1 YEAR LIMITED WARRANTY

READ AND SAVE MANUAL FOR FUTURE REFERENCE.

Assemble your griddle immediately.

Missing or damaged parts claims must be submitted within 30 days of purchase date.

For product inquiries, parts, warranty and troubleshooting support, please call 1-855-453-2150.



Master No. 211648

Manual Revision #: 01.11.2023 MZ



HEAVY ARTICLE NEEDS 2 TO LIFT

THIS MANUAL MUST REMAIN WITH THE PRODUCT AT ALL TIMES

To order non-warranty replacement parts or accessories, or to register your warranty, please visit us on the web at

www.masterchefbbqs.com

A CAUTION

Sharp edges. Wear gloves when assembling your barbecue.



A CAUTION

Read and follow all safety statements, assembly instructions, use and care directions before attempting to assemble and cook.



▲ INSTALLER OR ASSEMBLER/CONSUMER

This manual should be kept with the barbecue at all times.



▲ WARNING

Failure to follow all of the manufacturer's instructions could result in hazardous fires. explosions, property damage, or serious personal injury or even death.

Follow all leak check procedures carefully prior to operation of griddle, even if dealer assembled. Do not try to light without **A** WARNING reading the Lighting Instructions section of this manual.



DANGER

- 1. If you smell gas:
 - a. Shut off gas to the appliance.
 - b. Extinguish any open flame.
 - c. If odour continues, keep away from the appliance and immediately call your gas supplier or your fire department.
- 2. Requires two people to complete the assembly process.
- 3. Beware of sharp edges.



▲ WARNING

- 1. Do not store or use gasoline or other flammable liquids or vapours in the vicinity of this or any other appliance.
- 2. An LP cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.



IN DIRECT SUN, AND IN OPERATION, YOUR GRIDDLE 'S STAINLESS STEEL AND PAINTED STEEL PARTS CAN BECOME VERY HOT.

THIS GRIDDLE IS FOR OUTDOOR USE ONLY.


CONTACT CALL CENTRE IF ANY PARTS ARE MISSING.

TOOLS NEEDED FOR ASSEMBLY

- #2 Star-head screwdriver (long and short)
- ¼" Slotted screwdriver (long and short)
- Adjustable wrench
- Pliers


0049-9088 -13013-036	1 66
-13013-036	66
	00
0-42008-136	2
0042-9000	8
1101-9031	2
-10013-036	4
	4
	1101-9031 -10013-036 0017-9000

For correct hardware assembly, always position the lock washer between the screw and the flat washer.



A Caution:

Sheet metal can cause injury. Wear gloves when installing the griddle.




BEFORE ASSEMBLING THIS GRIDDLE, READ THE INSTRUCTIONS CAREFULLY.


Assemble the griddle on a flat, clean surface. Griddle is heavy; two people are recommended to complete assembly.


PARTS LIST FOR 085-0106 (G70220)


KEY#	QUANTITY	DESCRIPTION	PART NO.
AA	1	Griddle Top	G702-1700-01
AB	2	Hex Nut, Griddle	G329-1101-0
BA	1	Burner Box Assembly	G702-1100-0
BB	2	Burner, W/Gas Collector	G702-1200-0
BC	2	Electrode Set	G703-0902-0
BD	2	Burner	G702-1201-0
BE	 1	Control Panel	G702-3201-0
BF	 1	Manifold Assembly	G702-1500-0
BG	 1	Regulator	G702-1403-0
BH	4	Control Knob Bezel	G453-0092-010
BI	4	Control Knob	G364-3600-0
BJ	1	Grease Drain Tube	G702-1303-01
BK	1	Grease Cup	G703-1500-0
BL	1	Grease Cup Support	G702-1005-0
BM	3	Foil Insert	G703-0607-0
BN	2		G515-0044-0
DIN	2	Carry Over	G313-0044-0
CA	1	Side Shelf Support A	G702-1802-01
СВ	1	Side Shelf Support B	G702-1803-01
CC	1	Side Shelf Support C	G702-3301-01
CD	1	Side Shelf Support D	G702-3302-0
CE	1	Side Shelf Brace, Left	G702-0005-01
CF	1	Side Shelf Brace, Right	G702-0004-0
CG	2	Side Shelf	G702-3400-01
CH	2	Side Shelf Handle	G702-0001-01
CI	6	Tool Holder	G651-0005-01
DA	1	Bottom Shelf	G702-2701-01
DB	1	Cart Brace, Front	G702-3800-01
DC	2	Castor, Locking	G473-0017-0
DD	1	Front Leg, Left	G702-0300-0
DE	<u></u>		G702-0400-0
DF	<u></u>	Back Leg, Left Lower Cart Brace, Left	G702-0400-0
DG DG	<u></u>	<u> </u>	G702-0201-0
	1	Upper Cart Brace, Right	
DH	<u>-</u>	Front Leg, Right	G702-3000-0
DI	1	Back Leg, Right	G702-0700-0
DJ	1	Lower Cart Brace, Right	G702-0800-0
DK	1	Tank Support, Upper	G702-0501-0
DL	1	Tank Support, Lower	G702-0502-0
DM	1	Triangle Support, Left	G702-0803-0
DN	1	Triangle Support, Right	G702-0802-0
DO	2	Match Holder	G329-0002-02
DP DO	2	Castor, Fixed Upper Cart Brace, Left	G702-0203-01
DQ	1	opper cart brace, Lert	G702-0207-0
EA	1	Bottle Opener	A110-0020-0
 F1	1	Hardware Pack	G702-B020-0
F2	 1	Assembly Manual	G702-M001-01
F3	 1	Safety and Care Manual	G702-M001-02
	1	Surety and Care Manaal	G7 02-1000 1-


EXPLODED DIAGRAM FOR 085-0106 (G70220)
















ASSEMBLY INSTRUCTIONS

























X2





























ASSEMBLY INSTRUCTIONS







ASSEMBLY INSTRUCTIONS










A WARNING HOT SURFACES



CAUTION!

- AVOID BURNS!
- DO NOT TOUCH WHEN GRIDDLE IS IN USE!
- EXTREMELY HOT SURFACE!
- * SHADED AREAS BECOME EXTREMELY HOT WHEN IN USE.



Visit **www.masterchefbbqs.com** to complete product registration

MASTER Chef® Customer Service 1-855-453-2150